




Square Base




squarebase.a@outlook.com

INSTALLATIONS INSTRUCTIONS:



**FOR PIPE AND ANGLE IRON, USE SELF TAPPING SCREW, FENDER WASHER
(4) SCREWS FOR PIPE / (2) SCREWS FOR ANGLE IRON**



This sheet is meant only to highlight Square Base products and specifications. Information is subject to change without notice. As neither Square Base itself, nor its representatives practice architecture, Square Base offers no opinion on, and expressly disclaims any responsibility for the soundness of any structure on which its products may be applied. If questions arise as to the soundness of structure, or its ability to support planned installation properly, the Owner should obtain opinions of competent structural engineers before proceeding. Square Base accepts no liability for any structural failure or for resultant damages, and no Square Base representative is authorized to vary this disclaimer.